

- 1. <u>WARNING</u> Turn off the power. Before starting the installation, locate the circuit breaker in the electrical circuit panel and switch the circuit off. Turning *off* the light is not *sufficient* to prevent electrical shock.
- 2. Remove the old fixture. If you are replacing an existing fixture, remove all components of the old fixture (cover, mounting plate, etc...), remove the old wire connectors, and expose the supply wiring from the electrical box.
- 3. Connect the wires. Use a wire stripper to remove the protective coating of the wires. Connect the groundingwire (green or bare copper wire) from the electrical box to the green wire of the fixture. Connect the white wire from the electrical box to the white wire of the fixture. Connect the blackwire from the electrical box to the blackwire(s) of the fixture.
- 4. IMPORTANT. Use only UL Listed connectors and tape to complete the installation. Carefully read and follow any additional installation instructions provided in this sheet.

LIGHTWAY INDUSTRIES

VALENCIA CA 91355

INSTALLATION INSTRUCTIONS

M. ROA

REV

DESCRIPTION

VT Series Installation Sheet

DATE PARTNUMBER 12/11/2015 62-222-00

22-00 0